

	Frequency	PRESELECT	MHz	Main Dial	BAND	MODE
Amateur	kHz 1,910	2.0 1.8	2 0	9 1 0	B1.6~4.0	USB · CW
	3,525	3.6 3.3 90mb	4 3 2	5 2 5	B1.6~4.0	LSB
	7,050	8 7 41mb 49mb	8 7 6	0 5 0	C4.0~11.0	LSB
	14,175	15 13 19mb	15 14 13	1 7 5	D11.0~29.9	USB · CW
	21,225	23 20 13mb	22 21 20	2 2 5	D11.0~29.9	USB · CW
	28,850	30 26 11mb	29 28 27	8 5 0	D11.0~29.9	USB · CW
Medium Wave	590	0.6	1 0	5 9 0	A0.5~1.6	AM or AM/ANL
	980	1.0 0.8	1 0	9 8 0	A0.5~1.6	AM or AM/ANL
	1,170	1.2 1.0	2 1 0	1 7 0	A0.5~1.6	AM or AM/ANL
WWV/JJY	2,500	2.6 2.3 120mb	3 2 1	5 0 0	B1.6~4.0	AM or AM/ANL
	5,000	5 4 60mb	6 5 4	0	C4.0~11.0	AM or AM/ANL
	10,000	11 10 9 31mb	11 10	0	C4.0~11.0	AM or AM/ANL
	15,000	17 15 19mb	16 15 14	0	D11.0~29.9	AM or AM/ANL
Short Wave	3,925	4.0 3.6 75mb	4 3 2	9 2 5	B1.6~4.0	AM or AM/ANL
	5,980	6 49mb	6 5 4	9 8 0	C4.0~11.0	AM or AM/ANL
	9,715	10 9 31mb	9 8	7 1 5	C4.0~11.0	AM or AM/ANL
	11,705	12 11 25mb	12 11 10	7 0 5	D11.0~29.9	AM or AM/ANL
	15,120	17 15 19mb	16 15 14	1 2 0	D11.0~29.9	AM or AM/ANL
	17,880	20 17 16mb	18 17 16	8 8 0	D11.0~29.9	AM or AM/ANL
	21,550	23 20 13mb	22 21 20	5 5 0	D11.0~29.9	AM or AM/ANL

Table. 2